

## PLACING A CALL

- Dial 4-digit extension number  
OR Dial 8 + the external phone number  
OR press the Redial button


## ANSWERING AN INCOMING CALL

- Press your Prime blinking line key.  
(Prime line is the button that has your Ext number.)

## LOGGING IN/OUT OF THE PHONE

- If your phone is a Hot Desk phone (it will display LOCKED on the screen) you will need to login. Please follow these steps:
  - 1) After plugging in the phone
  - 2) Press button next to "Hot Desk" words displayed on the screen
  - 3) Press button next to "Login" displayed on the screen
  - 4) Enter your Ext #
  - 5) Press button next to "OK" displayed on the screen
  - 6) Enter your PIN (Same as your extension number)
  - 7) Press button next to "OK" displayed on the screen
- You will get a message "LOGIN COMPLETED"
- There is no need to logout from your phone, if you lose power or internet connectivity you will have to login following the steps above.

<sup>1</sup>Location of buttons and keys may vary per phone.



## MITEL MiCLOUD BUSINESS QUICK SETUP

### SETTING UP YOUR VOICE MAIL

#### FROM YOUR PHONE:

- Press VOICEMAIL soft button
- Passcode: 1111
- Follow the prompts to reset passcode and record your name, greeting, etc.

### ACCESSING VOICE MAIL

#### FROM YOUR PHONE:

- Press the “flashing envelope” key
- Press the READ MESSAGE soft key
- Press the CALL soft key
- Follow the prompts as instructed
- Passcode: \_\_\_\_\_

#### FROM ANY OTHER PHONE OR FROM OUTSIDE LINE:

- Dial DID directly, press the asterisk key “\*” upon answer and company greeting
- Follow the prompts as instructed
- Passcode: \_\_\_\_\_

